

USER MANUAL

Annunicom

Network-based, stand-alone intercom system for custom home installations and commercial applications



Firmware: Version 4.07

Released: October 2013

Supports:

- Annunicom 100
- Annunicom 200
- PS1
- Annunicom 60
- Annunicom 155
- IPAM 100
- IPAM 102
- IPAM 302

Table of Contents

1 Introduction	5
1.1 About the Annunicom	5
1.2 Features	5
1.3 Installing the Device	6
1.4 Additional Documents	6
1.5 Preloaded Firmware	6
1.6 About this manual	6
2 Controlling the Annunicom	7
2.1 User menu interface	8
2.2 Status and control	8
3 Configuration	11
3.2 Configuration Overview	11
3.3 Basic Settings	12
3.4 Advanced Settings	13
3.5 Table Settings	28
4 Reverting to factory defaults	30
5 Rebooting the device	31
6 Updating the device	32
6.1 STEP 1	32
6.2 STEP 2	32
6.3 STEP 3	33
6.4 STEP 4	33
7 The How To section	34
7.1 How to set the Annunicom for listening using WinAmp	34
7.2 How to listen using Windows Media Player	35
8 Application notes	38
8.1 Two station intercom	38
8.2 Door station and control station	42
9 Advanced user section	47
9.1 Network configuration using serial cable supplied	47
9.2 Network configuration using Telnet	49
9.3 Control APIs for serial and Ethernet	49
9.4 Expert settings	50
10 FAQ and Troubleshooting	51
11 Dictionary	52
12 Legal Information	54

1 Introduction

1.1 About the Annunicom

Congratulations on the purchase of your Annunicom from Barix AG.

What exactly is the Annunicom? The Annunicom is a network-based intercom, featuring fast setup, operation over existing network connections, flexible use and easy reconfiguration.

The Annunicom can work with other Annunicom devices in a standalone configuration or can seamlessly inter-operate with IT equipment like PCs.

Up to two buttons (Talk & Door, Talk & Emergency etc) plus relay output interface are available, which allow the use of the Annunicom in talk-back and door entry solutions.

Applications include

- Door intercom, talking over TCP/IP networks
- Alarming in public infrastructure, for example airports
- Remote paging connectivity via networks
- Residential intercom with network connectivity
- Automatic announcement systems

Each device can be configured to directly talk to up to 8 targets, via broadcast, or with the last calling station.

An unlimited number of communication partners can be selected via web browser or serial interface (directory connection).

The Annunicom is the ideal solution to monitor entrances and to provide intercom and alarming functionality in large residential, commercial and military building complexes like airports, office buildings, malls and residential housing areas. It can also be used along highways or in tunnels to provide IP based intercom capabilities.

No need for extra wiring when using existing network infrastructure or operating wireless, hence saving implementation time and costs. Using only standard TCP/IP protocols, connecting remote facilities is simple, and no changes to the existing WAN infrastructure are necessary.

1.2 Features

- Semi duplex two-way communication using mono audio streams.
- Choice of MPEG, G.711 and PCM audio formats.
- 10/100 Mbit Ethernet connection
- Two button input (e.g. Talk & Door) plus relay output interface
- Controllable via a standard web browser (PC, PDA, Web tablet) or via a serial port
- Line in, Line out, built in amplifiers for microphone and speaker
- Features SonicIP® and IPzator™ technology
- Easy integration into existing IT and intercom infrastructure

1.3 Installing the Device

For the installation of the Barix Annunicom devices please refer to the corresponding “Quick Install Guide”. A printed version is included in the box and can also be downloaded from our site www.barix.com.

1.4 Additional Documents

Technical specifications can be found in the corresponding product sheet which can be downloaded from our site www.barix.com.

For detailed technical information on the CGI application programming interface (API) please download the “Annunicom Technical Documentation” from our website.

1.5 Preloaded Firmware

Barix pre-loads the “Annunicom” firmware (from V4.06) on the Annunicom 100 and Annunicom 60 in a multi package with SIP. Please choose the annunicomic from the REBOOT page and reboot. If other HW is being used then the factory firmware will have to be replaced.

Before continuing with this manual make sure that the firmware version is up to date and corresponds with this manual. If not please proceed to the chapter “Updating the Device” in order to do so.

1.6 About this manual

1.6.1 Links to chapters

References to chapters (e.g. [X Chapter name](#)) are red and underlined and serve as direct links when viewed in Adobe Acrobat Viewer. Click on the link to jump to the referenced chapter.

1.6.2 Bookmarks pane in Adobe Acrobat

The complete “Table of Contents” is available in Adobe Acrobat Viewer. Click on the “Bookmarks” pane tab on the left side of Adobe Acrobat Viewer to open it. Click on any bookmark to directly jump to the corresponding part of the manual.

1.6.3 Chapter overview

This technical documentation is divided into the following chapters:

- [1 Introduction](#) (This chapter)
- [2 Controlling the Annunicom](#) (Controlling the Annunicom via the WEB UI)
- [3 Configuration](#) (How to configure the Annunicom)
- [4 Reverting to factory defaults](#) (Recovering the initial configuration)
- [5 Rebooting the device](#)
- [6 Updating the device](#) (How to update or change from “standard firmware”)
- [7 The “How To” section](#) (How to “listen” from Winamp or Media Player)
- [8 Application notes](#) (Two common applications)
- [9 Advanced user section](#) (Serial port and Telnet Network configuration)
- [10 FAQ and Troubleshooting](#)
- [11 Dictionary](#) (technical names and expressions used in this manual)
- [12 Legal Information](#)

2 Controlling the Annunicom

The Annunicom has a local web server built in so that you can control it from anywhere on your network using a standard web browser (from your PC, PDA or web tablet). This section describes the WEB UI as seen on the Annunicom 100. For other devices the pages are modified depending on what features are supported on that particular HW. In which case the help pages provide the required information. The Annunicom web server can be customized to meet installation requirements. Download the development kit from www.barix.com.

STEP 1

Open your web browser.

STEP 2

Type in the IP address of the Annunicom in the address bar then press Enter.

You should now see the **Home** page of the Annunicom in the browser window:

The screenshot shows the Annunicom web interface. At the top, there is a navigation bar with tabs: HOME, CONFIGURATION, STATUS, DEFAULTS, UPDATE, and REBOOT. The current page is titled "ANNUNICOM" and features the BARIX logo with the tagline "THE VOICE OF SIMPLICITY".

The main content area is divided into several sections:

- Stream:** Shows Streaming Mode (send on TALK) and Format (MPEG1 / 44.1 kHz (MP3)).
- Audio:** Includes Volume (50%), Peak Input (-21 dB), Peak Output (-∞ dB), and Input Source (radio buttons for LINE mono, MIC, and LINE stereo). The MIC button is currently selected.
- Status:** Shows the current status (IDLE) and buttons for FORCE, TALK, and STOP. Below this, there are links for Table (1) and Entry (ALL), along with a list of I/O controls (BUTTON 0, BUTTON 1, RELAY, CTS IN, RTS OUT) with SET and CLR links.
- Help (F3):** A sidebar on the right provides information about the current status of the device, including possible states (IDLE, INACTIVE, TALKING, TALKING SUPPRESSED, FORCED TALKING, LISTENING) and instructions on how to use the FORCE, TALK, and STOP buttons. It also includes a legend for the Status indicator: a grey square for "not talking", a green square for "talking", and a red square for "forced talking".

F1 Menu Frame

This frame allows selection of the Annunicom web server features. Click on the selection to go to the relevant section.

F2 Status and control

This frame shows the current device status. Several links allow control and simulation of button inputs, relay output and serial signals.

F3 Help

This frame shows the help for the available links in the device status page.

2.1 User menu interface



The menu frame is loaded once and remains in place as the following features are selected:

- Home
- Configuration
- Status
- Defaults
- Update
- Reboot

2.1.1 Red Bar

On the red bar is displayed the HW type, MAC address and the FW version loaded

2.1.2 Barix Logo

Clicking the Barix logo will bring you to the Barix homepage. (www.barix.com)

2.2 Status and control

Stream	Streaming Mode Format	send on TALK MPEG1 / 44.1 kHz (MP3)	
Audio	Volume	50 %	
	Peak Input	-27 dB	
	Peak Output	-∞ dB	
	Input Source	<input type="checkbox"/> LINE mono	<input checked="" type="checkbox"/> MIC
			<input type="checkbox"/> LINE stereo
Status	IDLE	<input type="checkbox"/>	<input type="button" value="FORCE"/> <input type="button" value="TALK"/> <input type="button" value="STOP"/>
	Table	1	1 2 3 4 5 6 7 8
	Entry	ALL	All 1 2 3 4 5 6 7 8
I/O	BUTTON 0	<input type="checkbox"/>	SET CLR
	BUTTON 1	<input type="checkbox"/>	SET CLR
	RELAY	<input type="checkbox"/>	PULSE SET CLR
	CTS IN	<input type="checkbox"/>	SET CLR
	RTS OUT	<input type="checkbox"/>	SET CLR

2.2.1 Stream

Shows the streaming mode and the audio format.

2.2.2 Audio

Shows the current Audio Input and Output Peak levels in dB, current volume in % and the audio input source.



Volume Slider

In the audio section there is an imbedded volume slider. The volume level can be adjusted in steps of 5% and has immediate affect. Click closer to the + (plus) sign for higher volume or closer to the – (dash) sign for lower volume. Clicking on the – (dash) sign decreases the volume by 5%. Clicking on the + (plus) sign increases the volume by 5%. The changes are temporary. On device reboot the volume returns to its configured setting.

2.2.3 Status

Shows the current audio status. ("IDLE", "TALKING", "TALKING SUPPRESSED", "FORCED TALKING" and "LISTENING"). Click the "FORCE" link to force talking This overrides the "LISTENING" mode, e.g. when an other device is talking to this device. Click the "TALK" link to start talking. Click the "STOP" link to stop talking. The Status indicator has the following meaning: GREY: not talking, GREEN: talking, RED: forced talking. On "*send always*" the buttons are not visible and the status is permanently set to "FORCED TALKING"

Table

Select the streaming table by number. Go to the configuration Basic or Table settings to create table entries.

Entry

Select "All" for talking to all configured entries within the table. Select a particular number to talk only to that entry.

2.2.4 I/O

The Annunicom software supports 2 digital inputs and 1 digital output. In addition CTS and RTS can also be used as digital input/output signals. Any signals not provided by the Annunicom HW are not displayed.

Button 0 and 1

Click the "SET" link to simulate the button being pushed.
Click the "CLR" link to simulate the button being released.
The indication next to "BUTTON" has the following meaning:
GREY: released, GREEN: pushed (simulation is not shown!)

Relay

Click the "TOGGLE" link to activate the relay for the "Relay toggle duration" time, adjustable in "Settings" under "I/O". Click the "SET" link to activate the relay, the "CLR" link to deactivate the relay. The indicator next to "RELAY" shows the physical status of the relay: GREY for inactivated, GREEN for activated.

CTS IN (RS-232)

Click the "SET" link to simulate CTS being activated. Click the "CLR" link to simulate CTS being deactivated. The indicator next to "CTS IN" shows the physical status of the CTS GREY: inactive, GREEN: active (simulation is not shown!)

-  - not activated
-  - activated

RTS OUT (RS-232)

Click the "SET" link to activate RTS. Click the "CLR" link to deactivate RTS. The indicator next to "RTS OUT" shows the physical status of the RTS:

-  - not activated
-  - activated

2.2.5 Supervision

One of the range of Annunicom HW, the Annunciocm 155, also supports supervision of microphone, speaker and temperature. On the Annunicom 155 the following fields are also displayed.

MIC

This field shows the status of the microphone:

-  - microphone detected and operating properly
-  - microphone not attached or short-cut detected

SPEAKER

This field is available only on devices supporting supervision. Shows the status of the attached speaker. The speaker is supervised with an in-band tone. The supervision must be configured in the Audio section and is by default off. The following values are displayed:

-  - supervision switched off or no value available yet
-  - speaker detected and operating properly
-  - speaker not attached or short-cut detected

TEMP

Shows the device's internal temperature in degrees centigrade. The information is available only on devices supporting supervision.

3 Configuration

To enter the Annunicom device configuration log onto its local web server.

3.1.1 STEP 1

Open your web browser

3.1.2 STEP 2

Type in the IP address of the Annunicom and press Enter

Example: 192.168.11.164

3.1.3 STEP 3

Click the Config button

CONFIGURATION

3.2 Configuration Overview

The screenshot shows the web configuration interface for an Annunicom device. The browser address bar shows the IP address 192.168.11.164/index.html. The page title is "BARIX Annunicom IC Status". The navigation menu includes HOME, CONFIGURATION (selected), STATUS, DEFAULTS, UPDATE, and REBOOT. The status bar at the top right displays "Annunicom 100 MAC: 00:08:E1:01:BC:11 FW VA4.06".

The main content area is titled "ANNUNCICOM" and features the BARIX logo with the tagline "THE VOICE OF SIMPLICITY". On the left, there are tabs for "Basic Settings" (selected), "Advanced Settings", and "Table Settings". Below these tabs are "Apply" and "Cancel" buttons.

The "BASIC SETTINGS" section includes:

- AUDIO**
 - Input source: Radio buttons for Line, Mic (selected), and Line Stereo.
 - Audio Format: A dropdown menu set to "MPEG1 / 44.1 kHz (MP3)".
 - Volume: A slider set to 50%.
- STREAMING**
 - Streaming Mode: A dropdown menu set to "send on TALK".
- STREAMING DESTINATION**
 - Table 1 Entry 1: A table with columns for Conn. type, IP #, #, #, #, and Port #. The values are: Raw UDP, 0, .0, .0, .0, :0.

On the right side, there is a detailed "AUDIO" section with the following information:

- Input Source:** Choose the desired input source. All input sources except "Line stereo" are mono. Default setting is "Mic".
- Audio Format:** Select encoding (data) format and sampling frequency. The formats are: MPEG, PCM (uncompressed digital audio), uLaw (G.711), A-Law (G.711). Default setting is "MPEG2 / 22.5 kHz".
- STREAMING**
 - Streaming Mode:** "send always" will stream always; "send on TALK" will stream if the TALK button (command) is pressed; "send on Level" will stream if the incoming audio signal is above the Trigger level; "auto answer" will stream back for the Post Trigger Play duration after a stream has been received; "receive only" can receive a stream but will never send one. Default setting is "send on TALK".

3.2.1 Configuration choices

From software version 4.06 the configuration is simplified to the following options:

- **Basic Settings**
Allowing the configuration of a simple use case, typically with two devices
- **Advanced Settings**
Allowing the configuration of all the parameters except the routing tables
- **Table Settings**
Allowing the configuration of all 64 table entries.

Within each of these 3 configuration groups, any parameters can be changed on multiple pages and applied once. This is an improvement over previous versions of the software which required parameters to be saved for every page. Use the “Apply” button to save all changes made in the current group. Use “Cancel” to cancel all changes.

3.2.2 Parameters

If Advanced or Table Settings is chosen a further menu choice is available to select a group of parameters. The menu selection is highlighted.

3.2.3 Help

Help is provided to configure each parameter. The help information is updated in parallel with the parameter menu selection.

3.3 Basic Settings

The Basic Settings allow the most common parameters to be set. For a description of the parameters refer to sections 3.4 Advanced Settings and 3.5 Table Settings below.

BASIC SETTINGS

AUDIO

Input source Line Mic Line Stereo

Audio Format MPEG1 / 44.1 kHz (MP3) ▼

Volume 50 ▼ %

STREAMING

Streaming Mode send on TALK ▼

STREAMING DESTINATION

Table 1 Entry 1

Conn. type	IP #	#	#	#	Port #
Raw UDP ▼	0	. 0	. 0	. 0	: 0

3.4 Advanced Settings

The screenshot shows the ANNUNICOM web interface. The browser address bar displays "192.168.11.164/index.html". The page title is "BARIX Annunicom IC Status". The navigation menu includes "HOME", "CONFIGURATION", "STATUS", "DEFAULTS", "UPDATE", and "REBOOT". The status bar shows "Annunicom 100 MAC: 00:08:E1:01:BC:11 FW VA4.06".

The main content area is titled "ANNUNICOM" and features the BARIX logo with the tagline "THE VOICE OF SIMPLICITY". A sidebar on the left lists settings categories: Basic Settings, Advanced Settings (selected), Network, Audio, Streaming, I/O, Serial, Control & SNMP, Security, and Table Settings. Below the sidebar are "Apply" and "Cancel" buttons.

The "NETWORK SETTINGS" section contains the following fields:

- Use SonicIP®**: Radio buttons for "Yes" (selected) and "No".
- IP Address**: Four input boxes, each containing "0".
- Netmask**: Four input boxes, each containing "0".
- Gateway IP Address**: Four input boxes, each containing "0".
- DHCP Host Name**: An empty text input field.
- Type of Service/DSCP**: An input box containing "40".

On the right side, there is a detailed "NETWORK SETTINGS" section with explanatory text:

NETWORK SETTINGS

Here a Static IP address can be configured for the device. This is recommended so that the device does not have to obtain an IP address on every power-up.

Use SonicIP®
If set to "yes", the device will announce its IP address over the audio output.
Default: "yes"

IP Address
Enter the 4 values of the desired device IP address e.g.:
"0.0.0.0" for automatic discovery (DHCP/Bootp, IPzator, AutolP),
"192.168.0.12" for an internal LAN
Default: "0.0.0.0"

Netmask
Enter the 4 values of the desired Static IP e.g.:
"0.0.0.0" for a default Netmask depending on the IP Address used, "255.255.255.0" for a C class network
Default: "255.255.255.0"

Gateway IP Address
Enter the 4 values of the desired Gateway IP address e.g.:

3.4.1 Network settings

Here a Static IP address can be configured for the device. This is recommended so that the device does not have to obtain an IP address on every power-up.

NETWORK SETTINGS

Use SonicIP® Yes No

IP Address . . .

Netmask . . .

Gateway IP Address . . .

DHCP Host Name

Type of Service/DSCP

Use SonicIP®

If set to "yes", the device will announce its IP address over the audio output.
Default: "yes"

IP Address

Enter the 4 values of the desired device IP address e.g.:

"0.0.0.0" for automatic discovery (DHCP/Bootp, IPzator, AutoIP), "192.168.0.12" for an internal LAN

Default: "0.0.0.0"

Netmask

Enter the 4 values of the desired Static IP e.g.:

"0.0.0.0" for a default Netmask depending on the IP Address used, "255.255.255.0" for a C class network

Default: "255.255.255.0"

Gateway IP Address

Enter the 4 values of the desired Gateway IP address e.g.:

"0.0.0.0" for no Gateway, "192.168.0.1" for a the LAN Gateway.

Note: The Gateway has to be set only when connecting to other devices over the WAN (through a router).

Default: "0.0.0.0"

DHCP Host Name

Name of the device sent in a DHCP request. If left empty, a name based on the device's MAC address is generated automatically. Enter up to 15 Characters.

Type of Service/DSCP

ToS value used for TCP and UDP streaming.

DSCP(Differentiated Service Code Point) supersedes IP4 ToS value and uses the same byte.

check for DSCP services available in your network to set this value. Valid values are 0-63.

Default value is 0.

3.4.2 Audio settings

These settings adjust the audio input and output.

Input section**Input source**

Choose the desired input source.

All input sources except "Line stereo" are mono. If you are using an Annunicom 200 a further option is available to select the SUB connector for Aiphone use. If this is selected the audio output will also be directed to the SUB interface. NOTE: Aiphone panels have a "ring" button which when pressed produces a signal on the SUB interface. This signal is used to trigger digital input 0 on the Annunicom. However, this signal may also be triggered by audio input and is, therefore, filtered out by the FW. For this filter to be effective, Aiphone panels should only be connected to the SUB interface if the SUB interface is selected as an input source.

Default setting is "Mic".

Speaker Also As Microphone

A speaker can be wired to an Annunicom so that it can also be used as a microphone.

In this case connect the speaker between (+) (A5) and ground (A3 or 4) instead of between (+) and (-) and connect (+) to the Microphone Input (A1). You will find the pin outs in the Annunicom Quick Install guides.

[Barix Annunicom Family](#)

For proper operation of the device this feature should only be selected if the speaker is wired as described.

Microphone gain

Choose the desired gain ("21" - "43.5" dB) for the microphone.

Default setting is "21" dB.

A/D amplifier gain

Choose the desired gain ("-3" - "19.5" dB) for the A/D amplifier.

AUDIO SETTINGS	
<u>Input section</u>	
Input source	<input type="radio"/> Line <input checked="" type="radio"/> Mic <input type="radio"/> Line Stereo
Speaker Also As Microphone	<input type="radio"/> enable <input checked="" type="radio"/> disable
Microphone gain	21 dB
A/D amplifier gain	-3 dB
Loop Input to Output	<input type="radio"/> Yes <input checked="" type="radio"/> No
Encoding	MPEG1 / 44.1 kHz (MP3)
MPEG Encoding quality (MP3 only)	7 Highest
<u>Output section</u>	
Volume	50 %
Bass	0
Treble	0
Loudness Level	20 <input type="radio"/> On <input checked="" type="radio"/> Off
Output Mode	<input checked="" type="radio"/> Mono <input type="radio"/> Stereo <input type="radio"/> Bridge
<u>Advanced Encoder Settings</u>	
MP3 Frame CRC	<input checked="" type="radio"/> enable <input type="radio"/> disable
MP3 Bitreservoir Mode	<input type="radio"/> used <input checked="" type="radio"/> kept empty
MP3 Copyright Protection	<input checked="" type="radio"/> enable <input type="radio"/> disable
MP3 Stream Type	<input checked="" type="radio"/> copy <input type="radio"/> original
MP3 Emphasis	none

Loop Input to Output

Choose "Yes" to hear the attached input on the local Line Out (For testing only, feedback may occur when using a speaker).

Default setting is "No".

Encoding

Choose between different encoding types (audio compression) and sampling frequencies.

From "MPEG1 / 48 kHz" down to "MPEG2 / 16 kHz" and "uLaw", "aLaw" or "PCM" at 8 or 24 kHz.

Default setting is "MPEG2 / 22.5 kHz".

MPEG Encoding Quality (MP3 only)

Choose between "0 lowest" and "7 highest" in steps of 1.

The Encoder Quality table below shows the average bit rate in kbit/s for the quality settings and sampling frequencies in kHz. Default setting is "0 lowest".

Qual.	0	1	2	3	4	5	6	7
44.1	65	68	73	80	90	105	125	140
22.05	35	38	40	45	50	60	75	90

Output Section

Volume

Choose between "0%" and "100%" in 5% steps.

Default: "50%"

Bass

Choose between "-10" and "10".

Default: "0"

Treble

Choose between "-10" and "10".

Default: "0"

Loudness Level

Choose between "0" and "20".

Default: "20"

Output Mode

Choose one of the "Mono", "Stereo" or "Bridge" settings.

The "Mono" mode produces a monophonic output signal out of both channels.

The "Stereo" mode lets both channels through.

The "Bridge" mode creates a mono differential left/right signal for connecting a single double-impedance speaker as a bridge between left and right channel.

Note: The "Stereo" and "Bridge" settings apply for stereo hardware only.

The output mode should correspond to the audio encoding used. The MPEG encoding is stereo, whereas uLaw, aLaw and PCM can transmit only monophonic signal.

Advanced Encoder Settings

MP3 Frame CRC

If set to "enable", the encoder will include the CRC-16 in each MP3 frame.

Default setting is "enable".

MP3 Bitreservoir Mode

The Bit reservoir is used to compensate the differences between the predefined frame sizes. If set to "used", the encoder will use the bit reservoir.

Default setting is "kept empty".

MP3 Copyright Protection

"Enable" or "disable" the copyright protection bit in the MP3 bitstream.

Default setting is "enable".

MP3 Stream Type

Select between a "copy" or an "original" bitstream in order to set the appropriate bit in the MP3 bitstream.

Default setting is "copy".

MP3 Emphasis

Select emphasis "none", "50/15 us" or "CCITT J.17".
Default setting is "none".

Supervision (Annunicom 155 only)**Speaker Supervision**

On the Annunicom 155 the attached loudspeaker can be supervised by the hardware. The supervision is done using a 11Hz tone injected into the signal. Status of the speaker is then displayed on the device's home page. Configure the supervision:

- *permanently off* - to disable the 11Hz tone and speaker monitoring
- *permanently on* - to enable the speaker monitoring permanently
- *periodic* - to enable the speaker monitoring in 1-minute intervals (10s tone pulses)

Default: "permanently off".

3.4.3 Streaming settings

These settings adjust the streaming mode, parameters and destinations.

STREAMING SETTINGS	
Own Name	<input type="text"/>
Streaming mode	send on TALK <input type="button" value="v"/>
Trigger Level	<input type="text" value="1000"/> only for mode "send on Level"
Pre Trigger Start	<input type="text" value="0"/> msec
Post Trigger Play	<input type="text" value="0"/> msec
Buffer Underrun Mode (TCP)	disconnect <input type="button" value="v"/>
Background Stream TCP Flow Control	throw away data <input type="button" value="v"/>
Stream Packet Strategy (MP3 only)	lowest latency <input type="button" value="v"/>
Non MP3 Packet Size	<input type="text" value="1200"/> Bytes
Play Buffer	<input type="text" value="4096"/> Bytes
Receive Timeout	<input type="text" value="200"/> msec
TCP Priority Rx Port	<input type="text" value="0"/>
UDP Priority Rx Port	<input type="text" value="0"/>
Minimum Priority Message Volume	<input type="text" value="25"/> %
UDP Receiver Port	<input type="text" value="3030"/>
UDP Tx Source Port	<input type="text" value="0"/>
Radio Path	<input type="text" value="/xstream"/>
Relay While Audio	OFF <input type="button" value="v"/>
Stream	<input checked="" type="radio"/> from table <input type="radio"/> to origin source
Current Table	1
Multicast Address	<input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/> . <input type="text" value="0"/>

Own Name

You can enter the name of the Annunicom here. This name will be returned when using the DISCOVER command (see technical documentation)

Default setting is "".

Streaming mode

"send always" will stream always

"send on TALK" will stream if the TALK button (command) is pressed

"send on Level" will stream if the incoming audio signal is above the Trigger level

"auto answer" will stream back for the Post Trigger Play duration after a stream has been received

"receive only" can receive a stream but will never send one

Default setting is *"send on TALK"*.

Trigger level

Is only used when Streaming mode is *"on Level"*.

Set to a value between 0 and 32767.

Open the Device status page and look for the Input peak value to get a hint for the trigger.

Default setting is *"1000"*.

Pre Trigger Start

Pre Trigger Start can be adjusted to prevent cut offs when audio should be sent earlier than detected. It defines the duration of the stream used before the actual trigger occurred.

This feature is normally used in combination with the send on level feature.

However, this parameter has a further use, to determine the receive stream strategy.

If 0, a minimum audio delay strategy is chosen at the receive side. Otherwise a minimum audio loss strategy is chosen.

Default setting is *"0"* milliseconds.

Post Trigger Play

Post Trigger Play can be adjusted to prevent cut offs when audio should be sent longer than detected. It defines the amount of time that the device will continue streaming after the actual trigger has been cleared.

This feature is normally used with the send on level feature. When Streaming mode is set to *"auto answer"* this defines the duration the device will stream back after a stream has been received.

Default setting is *"0"* milliseconds.

Buffer Underrun Mode (TCP)

The Buffer Underrun Mode (TCP) defines the action if a TCP stream is slower than the real stream from the encoder. In this case the output streaming buffer underruns and cannot hold older data anymore. The device can then *"disconnect"* the TCP connection or it can *"skip"* the stream directly to the encoder stream without disconnecting TCP.

Default setting is *"disconnect"*.

Background Stream TCP Flow Control

The Background Stream TCP Flow Control defines data receiving strategy of stream interrupted by a priority stream (so called background stream). If a priority stream is played, data in original stream can be either accepted and thrown away or the TCP connection can be stopped.

Use *throw away data* if your streaming source is streaming in real time (e.g. Annunicom). Use *stop stream* when the streaming source is sending data as fast as possible (e.g. when sending a file from a PC).

This setting is only for receiving data and does not affect UDP streams.

Streaming Strategy

The Streaming Strategy defines how a packet is built and sent. On "*lowest latency*" the encoded data will be sent directly after the encoding. On "*optimal package*" the packet will be filled up before sending. Default setting is "*lowest latency*".

Non MP3 Packet Size

The Non MP3 Packet Size defines with how many bytes a non MP3 packet will be filled up before it is sent. Set to a value between 1 and 1200. Default setting is "*1200*".

Play Buffer

Defines the amount of bytes that will be stored before playing the received stream. Lower this value to minimize delay, increase this value to prevent dropouts. Default setting is "*4096*" Bytes.

Receive Timeout

Defines the amount of time between the end of a received stream and switching to being able to send. Default setting is "*200*" msec.

TCP Priority Rx Port

Enter the port number for receiving a priority TCP stream. This stream always takes precedence. Set to a value between 0 (disabled) and 65535. Default port is "*0*".

UDP Priority Rx Port

Enter the port number for receiving a priority UDP stream. This stream always takes precedence. Set to a value between 0 (disabled) and 65535. Default port is "*0*".

Priority Message Minimum Volume

This is the guaranteed minimum volume for the priority message (received through UDP or TCP Priority Streaming Listen Port). If the current volume is less than this and priority message begins, the volume is set to this volume and reset back to original value when the message ends. Default: "*25%*".

UDP Receiver Port

Enter the port number for receiving a UDP stream. Set to a value between 0 (disabled) and 65535. Default port for UDP is "*3030*".

UDP Tx Source Port

This setting is only used when working with a custom software application. Enter the source port number to be used when sending a UDP stream. Set to a value between 0 and 65535. When set to 0 the port defined in the Stream table destination entry is taken. Or if Stream destination is set to "*origin source*" then the UDP Receiver Port is used. Default setting is "*0*".

Radio Path

Enter a radio path to listen to the transmitted stream of this Barix Annunicom using a device that is able to play MP3 radio stations (also PC software like WinAmp). The URL to connect is **http://x.x.x.x/p**. Where **x.x.x.x** is the IP address of this device and **/p** is this Radio path. Example: **http://192.168.0.24/xstream**
The device can serve up to 6 radio streams. Default setting is "*/xstream*".

Relay While Audio

Activate relay when sound is coming out of the analog output and deactivate when not.
Default setting is "OFF".

Stream

There are two ways streaming can be set up:

- 1) Automatically by responding to the last calling station
(to the device from where the last communication came, viz. "to the origin source").
- 2) By means of Tables containing IP addressing information.
Refer to section 3.5 Table Settings for information on configuring tables.

Choose if the stream should be sent to the defined entries in the table or "to the origin source".

Current Table

There are 8 tables available, each with 8 entries. Only one table is in use at any particular time.

This parameter shows the current table selected over the remote command interface or the home page.

Multicast Address

Enter a Multicast address on which to receive an audio stream. As receive port the "UDP Receiver Port" is taken. At start up the device will join the multicast group by periodically issuing IGMP join group messages.
Default setting is no address set, "0.0.0.0".

3.4.4 I/O Settings

These settings adjust the device behaviour for startup, inputs and outputs (attached buttons, the serial CTS signal and the relay pulse duration).

I/O SETTINGS	
Command Broadcasting	compatibility mode ▾
Init Sequence	<input type="text"/>
I0 pushed command	<input type="text" value="c=83"/>
I0 released command	<input type="text" value="c=84"/>
I1 pushed command	<input type="text" value="r=c=78"/>
I1 released command	<input type="text" value="r=c=79"/>
Relay pulse duration	<input type="text" value="30"/> x 0.1 sec (Door buzzing duration)
CTS close command	<input type="text" value="r=c=78"/>
CTS open command	<input type="text" value="r=c=79"/>
RTS pulse duration	<input type="text" value="0"/> x 0.1 sec

Command Broadcasting

This option is for backward compatibility with firmware versions prior to 1.16. If you want "r=c=" commands to be broadcast (UDP broadcast), set to *compatibility mode*. Otherwise choose *secure mode*, then "r=c=" commands will be sent only if *stream to origin source* is set and the origin source is known (command will be sent to the last partner).

Init Sequence

This command sequence is always executed immediately after startup (see further below for commands).

Default: ""

I0 pushed command

Configure which command should be issued when the I0 button is pushed (see further below for commands).

Default: "c=83"

I0 released command

Configure which command should be issued when the I0 button is released (see further below for commands).

Default: "c=84".

I1 pushed command

Configure which command should be issued when the I0 button is pushed (see further below for commands).

Default: "r=c=78"

I1 released command

Configure which command should be issued when the I0 button is released (see further below for commands).

Default: "r=c=79"

Relay pulse duration

Defines the amount of time (in tenths of a second) the door strike will buzz when the "Dout" pulse command is received.

Default: "30" (3 seconds)

CTS close command

Configures which command is issued when the CTS signal on the serial connector is activated (see further information below in the command description).

Default: "r=c=78"

CTS open command

Configures which command is issued when the CTS signal on the serial connector is deactivated (see further information below in the command description).

Default: "r=c=79"

RTS pulse duration

Defines the RTS pulse duration (in tenths of a second) when the "RTS" pulse command is received.

Default: "0".

Commands

Multiple commands can be added using the & character. They will be executed sequentially in the order that they appear in the configuration field.

TALKING MODE

c=83 : Activate the talking mode
c=84 : Deactivate the talking mode
c=91 : Activate the forced talking mode

STREAMING

c=77 : Set destination Syntax : c=77&entry=x&ip=a.b.c.d&port=p&type=t
For x use 1 to 8 (Streaming destination 1 to 8)
a.b.c.d is the IP address to stream to
p stands for the port number to be used
For t use 0 (not used), 1 (Raw UDP) or 2 (Raw TCP)

Example:

c=77&entry=2&ip=192.168.0.100&port=3030&type=1 sets the destination 2 to Raw UDP to IP 192.168.0.100 on port 3030

I/O

c=78 : Activate the relay
c=79 : Deactivate the relay
c=80 : Pulse the relay for the preset time
c=85 : Simulate the I0 button being pressed
c=86 : Simulate the I0 button being released
c=87 : Simulate the I1 button being pressed
c=88 : Simulate the I1 button being released

SERIAL

c=89 : Simulates the CTS Signal being activated
c=90 : Simulates the CTS Signal being deactivated
c=60 : Activates the RTS Signal
c=61 : Deactivates the RTS Signal

REMOTE COMMANDS

r=x : send the command x to the last calling station remotely
r=a.b.c.d:p/x : send the command x, using UDP, to the remote IP a.b.c.d on the optional port p. Default if no port is defined is the configured UDP command port.

Example:

r=192.168.0.99:12301/c=83 (sets the remote station to talking mode)

For further commands refer to the technical documentation available on www.barix.com.

3.4.5 Serial settings

These settings adjust the serial interface and serial gateway properties.

SERIAL SETTINGS	
Serial 1	
Baud rate	9600 ▼
Data bits	8 ▼
Parity	no ▼
Stop bits	1 ▼
Handshake	none ▼
Local port	12303
Destination IP	0 . 0 . 0 . 0
Destination port	0
Serial 2	
Baud rate	9600 ▼
Data bits	8 ▼
Parity	no ▼
Stop bits	1 ▼
Handshake	RS485 direction control ▼
Local port	12304
Destination IP	0 . 0 . 0 . 0
Destination port	0

Baud rate

Select the serial transmission speed ("300" to "115200" Baud).
Default: "9600"

Data bits

Select "7" or "8" data bits.
Default: "8"

Parity

Select "no", "even" or "odd" parity.
Default: "no"

Stop bits

Select "1" or "2" stop bits.
Default: "1"

Handshake

Select the type of handshake:

Note: on ports supporting only RS485, the Handshake should be set to: "RS485 direction control"

RTS/CTS lines not used: "none"

RS232/RS422: "Software flow control(XON/XOFF)" or "Hardware flow control (RTS/CTS)"

RS485: "RS485 direction control"

Note: on ports supporting only RS485, make sure the Handshake is set to: "RS485 direction control"

Default: "none" for Serial 1, "RS45 direction control" for Serial 2

Local port

Defines the network port on which the serial interface can be accessed for the gateway application. Only when "Local port" is set to "0" the serial interface can be used as a command interface.

If the serial gateway is enabled (Destination IP defined) and the "Local port" is set then this will be the source port of the TCP connection. On "0" a random source port is used.

Default: "12303"

Destination IP

To have this device actively establish a serial gateway select the destination IP address of the partner device.

Select "0.0.0.0" when the serial interface is only used locally.

Default: "0.0.0.0" (disabled)

Destination port

Defines the port for the active serial gateway function (see destination IP).

Default: "0" (disabled)

Notes

Both settings, "Destination IP" and "Destination port" have to be set to enable the gateway function.

Serial 2**Local port**

Defines the network port on which the 2nd serial interface can be accessed for the serial gateway application.

Default: "12304"

Destination IP

To have this device actively establish a serial gateway for serial port 2, select the destination IP address of the partner device.

Select "0.0.0.0" to disable.

Default: "0.0.0.0" (disabled)

Destination port

Defines the port for the active serial gateway function for serial port 2 (see destination IP).

Default: "0" (disabled)

3.4.6 Control and SNMP settings

The Annunicom provides two remote command interfaces: UDP and TCP. See the Technical Documentation for more details about the protocol.

UDP Command Port

Configure a port number between 1 and 65535 to enable the UDP command interface.

Enter 0 to disable the UDP command interface.

Default: "12301"

TCP Command Port

Configure a port number between 1 and 65535 to enable the TCP command interface.

Enter 0 to disable the TCP command interface.

Default: "12302"

CONTROL SETTINGS			
UDP command port	<input type="text" value="12301"/>		
TCP command port	<input type="text" value="12302"/>		
Web server port	<input type="text" value="0"/>		
Serial Interface 1	<input type="text" value="Command Interface"/>		
SNMP			
Trap Target IP Address	<input type="text" value="0"/>	<input type="text" value="."/>	<input type="text" value="0"/>
Low Audio Level	Left <input type="text" value="0"/>	Right <input type="text" value="0"/>	
High Audio Level	Left <input type="text" value="0"/>	Right <input type="text" value="0"/>	
Trap Repeat	Left <input type="text" value="0"/> sec	Right <input type="text" value="0"/> sec	
Silence Timeout	Left <input type="text" value="0"/> sec	Right <input type="text" value="0"/> sec	

Web server port

Defines the port where the webserver of the device can be reached. If set to "0" the default HTTP port (80) is used. Default: "0"

Serial Interface 1

Define the functionality of the 1st serial interface. "Command Interface" means the interface is used to input commands. "Keypad" disables the serial command interface and supports a keypad. Default: "Command Interface"

SNMP SETTINGS**Trap Target IP Address**

Enter the IP address of the SNMP trap destination. Default setting is "0.0.0.0".

Low Audio Level

Define the low audio level for the trap generation. A trap will be generated as soon as the audio level goes below this value (and the silence timeout is run out). Default setting is "0".

High Audio Level

Define the high audio level for the trap generation. A trap will be generated as soon as the audio level goes above this value. Default setting is "0".

Trap Repeat

Define the repeat interval for the SNMP trap sending. The trap will be repeated if the values are still according to the defined trap stages after this repeat time. Default setting is "0".

Silence Timeout

Define the time that has to run out before a trap is sent when the audio level is below the defined low audio value. Default setting is "0".

3.4.7 Security settings

These settings are used to secure access to the device on different levels. The status is shown next to each password ("set" or "not set"). Access is unrestricted for levels without a password (default setting).

SECURITY SETTINGS		
Level	Password	Status
Save Configuration	<input type="text"/>	not set
View Configuration	<input type="text"/>	not set
Control/Command	<input type="text"/>	not set
4 (User)	<input type="text"/>	not set
5 (User)	<input type="text"/>	not set
6 (User)	<input type="text"/>	not set
Listening	<input type="text" value="not protected"/>	
SNMP Community RWrite	<input type="text" value="not protected"/>	
SNMP Community Read	<input type="text" value="not protected"/>	

Save Configuration

Enter up to 24 characters to protect updates to the device configuration (Clicking the "Apply" button). Without a valid password the device configuration can not be saved!

Enter 25 characters to erase the current password.

Default: "not set"

Save configuration password usage

When the password is set the user has to type in the password in the "Save Config Password field" before hitting the "Apply" button. Without a valid password a warning will be displayed and the changes are not saved.

View Configuration

Enter up to 24 characters to protect viewing the device configuration (Clicking the "Config" button). Without a valid password the device configuration can not be viewed!


Enter 25 characters to erase the current password.

Default: "not set"

View configuration password usage

When the password is set login in using the the pop up window (the user name does not matter).

Only one user can log in at a time. Further attempts will be refused.



To log out click on the "Logout" link

Please widen the device window if the "Logout" link is not visible.

Control / Command

Enter up to 24 characters to secure the access to all control and command interfaces (WEB/CGI, Serial, TCP, and UDP). Without a valid password the device can not be controlled.

Enter 25 characters to erase the current password.

Default: *"not set"*

Note

This security option should be used very carefully and is intended for advanced users only. Since the CGI commands used in the web interface do not make use of passwords, setting this password would disable any control of the device using a browser.

Level 4 to 6 (User)

Enter up to 24 characters to secure the access to customized web pages in 3 levels. Intended for advanced users only, for details see the Technical Documentation. Without a valid password these user web pages cannot be viewed.

Enter 25 characters to erase the current password.

Default: *"not set"*

Listening

Choose which level is used for preventing unauthorized listeners from listening to Annunicom as Internet Radio, or "not protected" for access for all.

SNMP Community RWrite

Choose a password for the Read and Write Community, or "not protected" to ignore both the read and write communities or "no write access"

SNMP Community Read

Choose a password for the Read Community, or "not protected" to ignore the read community or "no access"

Note that the Community RWrite setting takes priority. This means that if the Community RWrite is set to not protected, Community Read is ignored.

3.5 Table Settings

These settings adjust the table entries.

The screenshot shows the ANNUNICOM configuration web interface. At the top, there is a navigation menu with options: HOME, CONFIGURATION, STATUS, DEFAULTS, UPDATE, and REBOOT. The status bar indicates 'Annunicom 100 MAC: 00:08:E1:04:BC:11 FW VA4.06'. The main heading is 'ANNUNICOM' with the logo 'BARIX THE VOICE OF SIMPLICITY'. On the left, a sidebar menu shows 'Basic Settings', 'Advanced Settings', and 'Table Settings' (selected). Under 'Table Settings', there are links for Table 1 through Table 8. The main content area is titled 'STREAMING TABLE 1' and contains a table with 8 entries. Each entry has a 'Conn. type' dropdown menu and four IP address input fields followed by a 'Port #' input field. Entry 1 is configured with 'Raw UDP' and IP address '0.0.0.0' on port 0. Entries 2 through 8 are set to 'not used'. At the bottom left of the table settings are 'Apply' and 'Cancel' buttons. On the right, a help panel titled 'These settings adjust the table entries.' provides detailed instructions for the 'Table', 'Conn. type', and 'IP # # # #' fields.

Entry	Conn. type	IP #	#	#	#	Port #
1	Raw UDP	0	0	0	0	0
2	not used	0	0	0	0	0
3	not used	0	0	0	0	0
4	not used	0	0	0	0	0
5	not used	0	0	0	0	0
6	not used	0	0	0	0	0
7	not used	0	0	0	0	0
8	not used	0	0	0	0	0

Table
There are up to 8 entries in a table. Each entry can be configured to stream to a device, a multi- or broadcast address or to be a listener (server).
The numbered links will allow you to configure additional tables which can be selected over the command interface during operation.

Conn. type
Choose the type of connection:
"not used" for unused entries
"Internet Radio" for an internet radio station (1 user) (default)
"Raw UDP" for a UDP connection
"Raw TCP" for a TCP connection

IP # # # #
Enter 4 values of the entry IP address e.g.:
"0.0.0.0" for unused entries (except when the connection type is set to UDP it will be broadcasted e.g. "192.168.0.255")
"0.0.0.0" for connection TCP + Port if this device is used as a TCP listener waiting for a connection from a streaming device. (default)
"192.168.0.34" for a directed connection
"192.168.0.255" for a broadcast

Table

Up to 8 entries can be set in a table. Each entry can be configured to stream to a device, a multi- or broadcast address or to be a listener (server).

The numbered links (Table 1, Table 2 etc.) allow additional tables to be configured which can then be selected via the home page or over the command interface. Only the configured Current Table (see section 3.4.3 Streaming settings) is active at a particular time.

Conn. type

Choose the type of connection:

"not used" for unused entries

"Internet Radio" for an internet radio station (1 user) (default)

"Raw UDP" for a UDP connection

"Raw TCP" for a TCP connection

IP # # #

Enter 4 values of the entry IP address e.g.:

"0.0.0.0" for unused entries (except when the connection type is set to UDP it will be broadcasted e.g.

"192.168.0.255")

"0.0.0.0" for connection TCP + Port if this device is used as a TCP listener waiting for a connection from a streaming device. (default)

"192.168.0.34" for a directed connection

"192.168.0.255" for a broadcast

Default settings:

Entry # 1 in table 1 "Raw UDP 0.0.0.0:0". This means it is UDP broadcasting on port 3030!

All other entries are set to "not used" except for table 1 where all entries are set to "Internet Radio 0.0.0.0:0".

Port #

Enter the port number for each entry (between "0" and "65535"). If this port is set to "0" then the default ports are used (Internet Radio "80", TCP "2020", UDP "UDP Receiver Port" or if "0" then "3030"). Default setting is "0".

Notes

The choice of settings to distribute the stream to the other station(s) depends on your environment and desired functionality.

If the reception of up to 8 streams need to be guaranteed we recommend using TCP since lost packets are retransmitted automatically.

If the stream is intended to be received by many devices we recommend using UDP broadcast (as long as all devices are on the LAN as broadcast is not passed over a WAN by the routers).

If your network infrastructure is capable of multicasting use multicast to reduce the traffic generated by broadcasting.

A mix of all the above is possible as each of the 8 destinations allow an individual choice of connection type.


4 Reverting to factory defaults

Click on the DEFAULTS button to enter the defaults page.

You will see the following screen:



Click on "Factory defaults" to revert all settings except "Network configuration" to factory defaults. While restarting the device the following screen appears showing a number counting down:



Upon start up the following screen appears stating the successful reverting to factory defaults:



Hard default settings

To revert all settings (including the network settings) to factory defaults the Reset button has to be pressed for about 5 seconds while the Annunicom is powered.

Important note

Use this method if a connection to the Annunicom cannot be established. This can happen if you have set a Static IP address once, switched off Sonic IP and then forgotten the IP address.

The Hard default settings sets the IP Address to automatic discovery (0.0.0.0) and enables SonicIP.

If this fails we recommend downloading the Annunicom Rescue Kit from www.barix.com.


Unzip the Kit and read "readme1st.txt" for instructions.

This Rescue Kit reloads the entire firmware, resets the device to factory default settings using the supplied serial cross cable and a PC running W2K or XP.

5 Rebooting the device


Click on the REBOOT button to enter the reboot page.

You will see the following screen:




Click "Reboot the device" to restart the Annunicom.

While restarting the device the following screen appears showing a number counting down:



Upon start up the following screen appears stating the successful restart:



6 Updating the device

Barix constantly enhances the capabilities of their products. Therefore we recommend keeping the software on the Annunicom up-to-date. To download the latest firmware version please visit www.barix.com.

Click on [downloads](#) and then click on [Annunicom](#).

Scroll down to the section [Firmware](#). Download the firmware update package and unpack to a local drive. If your device can not be reached over the network using a browser the Rescue Kit can be used.

Read "readme1st.txt" for instructions. This Rescue Kit reloads the entire firmware, resets the device to factory default settings using the supplied serial cross cable and a PC running W2K or XP.

If your device is reachable by browser follow the next steps to update the device over the network.

6.1 STEP 1

Click on the UPDATE button to enter the update page.

You will see the following screen:

UPDATE

Please read the instructions before applying the update.

[Please click here to start the update](#)

Currently Loaded Version

Firmware	VA4.06 (01/21/2013)
Web UI	V02.00
Bootloader	V99.26
Setup	V01.05
Song	V09.23 (Jan 21 2013)
XT	V00.03

6.2 STEP 2

In order to upload a new firmware click on "Please click here to start the update".

After a count-down the device will restart in a special mode called Bootloader.

Please note that in this mode the standard HTTP port 80 is **always** used.

The device is restarting now. Please wait.

3

Please click [here](#) after the countdown if your browser doesn't support forwarding.

Upon start up the following screen appears ready for the update process.



Update

Resource

[Advanced Update](#)

6.3 STEP 3

To upload an update click on "Browse..." to locate the file you want to update.

The file is named compound.bin If you load the wrong file the device will not work and then the Rescue Kit must be used.

Click the "Upload" button and wait for a confirmation of the upload.

Do not interrupt the upload process, reset or power off the device until the firmware is loaded.

After the file completely loads, click on update and then press the "reboot" button to restart the device with the new firmware. The device takes a few seconds to reboot.

6.4 STEP 4

Click on the "here" link to reload the devices main page.

7 The “How To” section

7.1 How to set the Annunicom for listening using WinAmp

Follow these steps to ensure correct settings in the Annunicom.

7.1.1 STEP 1

Open your Web Browser

7.1.2 STEP 2

Type in the IP address of the Annunicom and hit enter.

Example: 192.168.0.12

7.1.3 STEP 3

Click on the Configuration link.

7.1.4 STEP 4

Click on the STREAMING tab in the SETTINGS menu

7.1.5 STEP 5

Choose "send always" in the Streaming mode field.

7.1.6 STEP 6


Make sure that Radio Path says: **/xstream** and that at least one entry in the active table (usually table 1) is set to "Internet Radio 0.0.0.0 : 0"

7.1.7 STEP 7


Open WinAmp

7.1.8 STEP 8

Under the file menu choose Play Location (Play URL in version 5) or hit CTRL and L on your keyboard.



7.1.9 STEP 9



Enter the IP address of your Annunicom followed by /xstream.

Example: *192.168.0.12/xstream*

Hit the Open button.

7.1.10 STEP 10

WinAmp will open the stream and buffer it. Wait a few seconds (to fill the buffer) before you can hear the input signal in WinAmp.



7.1.11 NOTE

Once this works you can also try to set the Streaming mode to "send on TALK/CTS". Every time TALK is activated WinAmp will start playing.


Also test the impact of different Quality and Sampling frequency settings. Play with the Buffer settings in WinAmp to reduce dropouts or minimize delays.

7.2 How to listen using Windows Media Player

Follow the steps 1 to 6 in chapter 8.1 to ensure correct settings in the Annunicom.

7.2.1 STEP 1

Open your Windows Media Player and click on Open URL under the menu File.




Enter the IP address of your Annunicom followed by /xstream. Example: *192.168.0.5/xstream*

Hit the OK button.

7.2.2 STEP 2

The Media Player will open the stream and connect to the Annunicom. This is indicated by a single “)” going from left to right and back in the stream bar on the bottom right.




7.2.3 STEP 3

The Media Player will connect and indicate this by the Play button appearing and a steady display of two “))” in the stream bar on the bottom right and as buffering proceeds the number of “))” will increase.




7.2.4 STEP 4

The Media Player is programmed for playing streams from a server and calculates the buffer automatically. Because the Annunicom is streaming in real-time the buffer calculation assumes a slow connection and would buffer for about 2 minutes. This can be shortened by clicking on the Play button. The playback then starts immediately.



7.2.5 STEP 5

If you think that the delay is too big the Media Player can be tuned to shorten it. Change the setting in the Performance Tab (under the menu Tools/Options) as shown below and make sure that you click on Play as soon as the button appears.




8 Application notes

This section will show you how to set the Annunicom devices in common applications.

8.1 Two station intercom

Situation: two stations with one TALK button each.

Annunicom's default settings are already configured to allow two station intercom with only a few changes.



8.1.1 Station 1 configuration

Wiring

Station 1 is connected to an intercom panel:
 Speaker to speaker out (C).
 Microphone to Microphone In (E or F).
 The TALK button to Input 0 (B1 and B3).

Network settings

If you have a DHCP Server in your network the device will automatically get an IP address and no changes are needed.

Skip this step and go to Audio settings.


Use the following settings if you prefer to have a Static IP or if no DHCP server is available.

The screenshot shows a network configuration window with the following fields:

IP Address	192	.	168	.	0	.	10
Netmask	0	.	0	.	0	.	0
Gateway IP Address	0	.	0	.	0	.	0
Use SonicIP®	<input type="radio"/> Yes <input checked="" type="radio"/> No						

SonicIP is disabled; no need to hear it on power up as the IP Address is static and known and the device will stay powered most of the time.

Audio settings



Input section

Input source: Line Mic Detect Source

Microphone gain: 21 dB

A/D amplifier gain: -3 dB

Loop Input to Output (MP3 only): Yes No

Encoding: MPEG1 / 44.1 kHz (MP3)

MPEG Encoding quality (MP3 only): 7 Highest

Output section

Volume: 50 %

Bass: 0

Treble: 0


Loudness Level: 20 On Off

Change the Input source to "Mic".

The Microphone Gain as well as the Volume might need adjustment later on depending on the microphone and speaker used.

Quality and Sampling frequency settings can be decreased to lower the network traffic but this will increase the playback delay.

Streaming settings



Own Name: Station 1

Streaming mode: send on TALK

Trigger Level: 1000 only for mode "send on Level"

Pre Trigger Start: 0 msec

Post Trigger Play: 0 msec

Buffer Underrun Mode (TCP): disconnect

Background Stream TCP Flow Control: throw away data

Stream Packet Strategy (MP3 only): lowest latency

Non MP3 Packet Size: 1200 Bytes

Play Buffer: 4096 Bytes

No changes needed.

Streaming mode is set to talk when the TALK command is activated (i.e. TALK button pressed).
 Post Trigger Play is set to talk on for 1 second after the button has been released. This prevents cut offs.
 When receiving a stream, 4096 Bytes will be buffered first before playing it back over the speaker. Lower this value to minimize delay, increase this value to prevent dropouts.
 The stream will be transmitted using a UDP broadcast on port 3030.

IO settings

Command Broadcasting	compatibility mode
Init Sequence	
IO pushed command	c=83
IO released command	c=84

No changes needed.

The IO pushed command c=83 will activate the TALK mode when the TALK button is pressed.
The IO released command c=84 will deactivate the TALK mode when the TALK button is released.

Security settings

These settings need not to be changed for now.
Adjust them later according to your security needs.

Adjustments for Station 1 are completed.

8.1.2 Station 2 configuration

Wiring

Station 2 is connected to an Intercom panel:
Speaker to speaker out (C).
Microphone to Microphone In (E or F).
The TALK button to Input 0 (B1 and B3).

Network settings

If you have a DHCP Server in your network the device will automatically get an IP address and no changes are needed.


Skip this step and go to Audio settings.

Use the following settings if you prefer to have a Static IP or if no DHCP server is available.

IP Address	192	.	168	.	0	.	20
Netmask	0	.	0	.	0	.	0
Gateway IP Address	0	.	0	.	0	.	0
Use SonicIP®	<input type="radio"/> Yes <input checked="" type="radio"/> No						

SonicIP is disabled; no need to hear it on power up as the IP Address is static and known and the device will stay powered most of the time.

Audio settings



Input section

Input source Line Mic Detect Source

Microphone gain 21 dB

A/D amplifier gain -3 dB

Loop Input to Output (MP3 only) Yes No

Encoding MPEG1 / 44.1 kHz (MP3)

MPEG Encoding quality (MP3 only) 7 Highest

Output section

Volume 50 %

Bass 0

Treble 0

Loudness Level 20 On Off

Change the Input source to "Mic".

The Microphone Gain as well as the Volume might need adjustment later on depending on the microphone and speaker used.

Quality and Sampling frequency settings can be increased to lower the playback delay but this will slightly increase network traffic.

Streaming settings

No changes needed.

See details under Station 1 configuration.

IO settings

No changes needed.

See details under Station 1 configuration.

Security settings

These settings need not to be changed for now.
Adjust them later according to your security needs.

8.2 Door station and control station

Situation: one door and one control station. A visitor can push the RING button to activate the buzzer on the control station. Pushing the TALK button on the control station permits to talk to the door station. When releasing the TALK button the visitor can talk for a predefined time. Pushing the DOOR button on the control station will activate the door strike to let the visitor in.

Door station
192.168.0.10

LAN

Control station
192.168.0.20



8.2.1 Door station configuration

Wiring

The door station is connected to an intercom panel: Speaker to speaker out (C).
Microphone to Microphone In (E or F).
The RING button to Input 1 (B2 and B3).
The door strike to Relay normally open (B4) and Relay common (B5).

Network settings

IP Address	192	.	168	.	0	.	10
Netmask	0	.	0	.	0	.	0
Gateway IP Address	0	.	0	.	0	.	0
Use SonicIP®	<input type="radio"/> Yes <input checked="" type="radio"/> No						

SonicIP is disabled; no need to hear it on power up as the IP Address is static and known and the device will stay powered most of the time.

Audio settings

Change the Input source to "Mic".

The Microphone Gain might need adjustment later on depending on the used microphone.

Same goes for Volume depending on the speaker.

Quality and Sampling frequency settings can be increased to lower the playback delay but this will increase network traffic slightly.

Input section

Input source: Line Mic Detect Source

Microphone gain: 21 dB

A/D amplifier gain: -3 dB

Loop Input to Output (MP3 only): Yes No

Encoding: MPEG1 / 44.1 kHz (MP3)

MPEG Encoding quality (MP3 only): 7 Highest

Output section

Volume: 50 %

Bass: 0

Treble: 0

Loudness Level: 20 On Off

Streaming settings

Own Name: Door

Streaming mode: auto answer

Trigger Level: 1000 only for mode "send on Level"

Pre Trigger Start: 0 msec

Post Trigger Play: 12000 msec

Buffer Underrun Mode (TCP): disconnect

Background Stream TCP Flow Control: throw away data

Stream Packet Strategy (MP3 only): lowest latency

Non MP3 Packet Size: 1200 Bytes

Play Buffer: 4096 Bytes

The door station is set to auto answer for 12 seconds (Post Trigger Play) using UDP broadcast.

When receiving a stream, 4096 Bytes will be buffered first before playing it back over the speaker. Lower this value to minimize delay, increase this value to prevent dropouts.

TABLE 1

Entry	Conn. type	IP #	#	#	#	Port #
1	Raw UDP	0	0	0	0	0

The stream will be transmitted using a UDP broadcast on port 3030.

IO settings

Command Broadcasting	compatibility mode
Init Sequence	
I0 pushed command	c=83
I0 released command	c=84
I1 pushed command	r=192.168.0.20/c=80
I1 released command	

The I1 pushed command r=192.168.0.20/c=80 will activate the relay on the control station for the Relay toggle duration time set in the control station when the RING button is pressed on the door station panel.

The I1 released command has to be blank.

Adjust the Relay toggle duration according to the specification of the door strike used.

All other commands are not used and can be left blank or as is.

Security settings

These settings need not to be changed for now.

Adjust them later according to your security needs.

8.2.2 Control station configuration

Lets take a look on how to configure the control station.

Wiring

The control station is connected to an intercom panel: Speaker to speaker out (C).

Microphone to Microphone In (E or F).

The TALK button to Input 0 (B1 and B3).

The DOOR button to Input 1 (B2 and B3).

The flash or buzzer to Relay normally open (B4) and Relay common (B5).

Network settings

IP Address	192	.	168	.	0	.	20
Netmask	0	.	0	.	0	.	0
Gateway IP Address	0	.	0	.	0	.	0
Use SonicIP®	<input type="radio"/> Yes <input checked="" type="radio"/> No						

SonicIP is disabled, no need to hear it on power up as the IP is static and known and will not be power cycled anyway.

Audio settings

Change the Input source to "Mic".

See details under Door station configuration.

Streaming settings

No changes needed.

The control station is set to talk only when the Talk button is pushed using UDP broadcast.

Pre Trigger Start can be adjusted to prevent cut offs when starting to talk too early.

Post Trigger Play can be adjusted to prevent cut offs after the button has been released.


When receiving a stream, 4096 Bytes will be buffered first before playing it back over the speaker. Lower this value to minimize delay, increase this value to prevent dropouts.

TABLE 1

Entry	Conn. type	IP #	#	#	#	Port #
1	Raw UDP	0	0	0	0	0

The stream will be transmitted using a UDP broadcast on port 3030.

IO settings



The IO pushed command c=83 will activate the TALKING mode in the control station when the Talk button is pressed on the control station panel and deactivated when released (c=84).

The I1 pushed command r=c=78 will activate the relay on the door station and hence open the door strike as long the DOOR button is pushed.

To prevent the door from being opened by pressing the door button without someone first pushing the Bell button change the Command Broadcasting to “secure mode”

The I1 released command r=c=78 will deactivate the relay on the door station and hence lock the door.

Another way is to use a pulse command instead:

Change the I1 pushed command to r=c=80 and leave the I1 released command blank. Adjust the Relay pulse duration on the other station according to the spec of the used door strike.

Adjust the Relay pulse duration according to your needs of the flash or buzzer duration. The setting 30 means that the flash will light up (or the buzzer will sound) for 3 seconds when someone pushes the Ring button at the door.

All other commands are not used and can be left blank or as is.

Security settings

These settings need not to be changed for now.
Adjust them later according to your security needs.

For further application notes please visit www.barix.com.

9 Advanced user section

9.1 Network configuration using serial cable supplied

9.1.1 STEP 1

Open a Terminal program.

9.1.2 STEP 2

Go to the settings menu and adjust the following settings: Baud rate 9600 bit/sec, 8 Data Bits, no Parity and 1 Stop Bit.

9.1.3 STEP 3


Unplug the power supply of the Annunicom.

9.1.4 STEP 4

Connect the supplied serial cable to your PC's COM port and to the serial port of the Annunicom.


9.1.5 STEP 5

Keep the Reset button pushed and plug in the power supply. Release the Reset button as soon as you see the following screen:



9.1.6 STEP 6

Hit <S> to skip network discovery if not connected to a network and the following screen appears:



9.1.7 STEP 7

Hit <S> to get to the Annunicom setup.

```

Comm2 - HyperTerminal
Datei Bearbeiten Ansicht Anrufen Übertragung ?
FACTORY key pressed!
Bootloader V99.05 0008E1000E1F
Press 's' or the reset button to skip network 1
-----
Page 0 (F000): FW0106 Page 1 (F100): ----- Page 2 (F200): FW0001
Page 3 (F300): FW0203 Page 4 (F400): -CoB1- Page 5 (F500): -CoB1-
Page 6 (F600): ??????? Page 7 (F700): ----- Page 8 (F800): -----
Page 9 (F900): ----- Page 10 (FA00): ----- Page 11 (FB00): -----
Page 12 (FC00): ----- Page 13 (FD00): ----- Page 14 (FE00): -----
-----
s) setup
u) upload page
f) factory test
e) exec page
c) clear page C) clear flash E) clear EEPROM
m) monitor
r) reset
*** BARIK Device ***
Press Enter to go into Setup Mode
Verbunden 00:01:13 Autom. Erkenn. 9600 8-N-1 [RF] [GROSS] [RF] Aufzeichnen Druckerscho

```

9.1.8 STEP 8

Hit <enter> to enter the Annunicom setup mode.

```

Comm2 - HyperTerminal
Datei Bearbeiten Ansicht Anrufen Übertragung ?
Page 6 (F600): ??????? Page 7 (F700): ----- Page 8 (F800): -----
Page 9 (F900): ----- Page 10 (FA00): ----- Page 11 (FB00): -----
Page 12 (FC00): ----- Page 13 (FD00): ----- Page 14 (FE00): -----
-----
s) setup
u) upload page
f) factory test
e) exec page
c) clear page C) clear flash E) clear EEPROM
m) monitor
r) reset
*** BARIK Device ***
Press Enter to go into Setup Mode
*** basic parameters
IP addr - 0.0.0.0/DHCP/BOOTP/AutoIP, no gateway set
DHCP device name : not set
Change Setup : 0 Network
                8 Exit without save
                9 Save and exit
                Your choice ?
Verbunden 00:05:58 Autom. Erkenn. 9600 8-N-1 [RF] [GROSS] [RF] Aufzeichnen Druckerscho

```

9.1.9 STEP 9

Type in <0> and hit <enter> to enter the Network configuration. Enter all requested values:

```

Comm2 - HyperTerminal
Datei Bearbeiten Ansicht Anrufen Übertragung ?
c) clear page C) clear flash E) clear EEPROM
m) monitor
r) reset
*** BARIK Device ***
Press Enter to go into Setup Mode
*** basic parameters
IP addr - 0.0.0.0/DHCP/BOOTP/AutoIP, no gateway set
DHCP device name : not set
Change Setup : 0 Network
                8 Exit without save
                9 Save and exit
                Your choice ? 0
IP Address : ( 0) 192.( 0) 168.( 0) 0.( 0) 10
Set Gateway IP Address (N) N
Netmask: Number of Bits for Host Part (0=default) (0) 8
Change telnet config password (N) N
Change Setup : 0 Network
                8 Exit without save
                9 Save and exit
                Your choice ? _
Verbunden 00:01:30 Autom. Erkenn. 9600 8-N-1 [RF] [GROSS] [RF] Aufzeichnen Druckerscho

```

9.1.10 STEP 10

Type in <9> and hit <enter> to save the Network configuration.

9.2 Network configuration using Telnet

9.2.1 STEP 1

Unplug the power supply of the Annunicom.

9.2.2 STEP 2

Keep the Reset button pushed and plug in the power supply. Release the Reset button after 5 seconds.

9.2.3 STEP 3

Run a command session. Type telnet with the IP address announced by SonicIP on port 9999.

Example: telnet 192.168.0.168 9999

You will see the following screen:



```

Engabeaufforderung - telnet 192.168.0.168 9999
*** BARIX Device ***
Press Enter to go into Setup Mode
  
```

Hit <enter> to access the Annunicom in the setup mode.



```

Engabeaufforderung - telnet 192.168.0.168 9999
*** BARIX Device ***
Press Enter to go into Setup Mode

*** basic parameters
IP addr : 0.0.0.0/BHCP/B00FP/AutoIP, no gateway set
BHCP device name : not set

Change Setup : 0 Network
               1 Exit without save
               2 Save and exit
Your choice ? =
  
```

9.2.4 STEP 4

Type in <0> and hit <enter> to enter the Network configuration. Enter all requested values.

9.2.5 STEP 5

Type in <9> and hit <enter> to save the Network configuration.

9.3 Control APIs for serial and Ethernet

For integration of the Annunicom into various control applications and home automation systems, Barix has developed a control API (Application Protocol Interface) for the serial port and Ethernet UDP and TCP control.

9.3.1 Serial Port control API

The serial port on the Annunicom can be used to send control commands from a home automation system and other PC or embedded applications. In the device configuration the serial port can be adjusted to suit your application.

For a detailed list of serial commands refer to the Annunicom Technical Documentation available on the Barix website www.barix.com

9.3.2 Ethernet UDP or TCP control commands

The same control commands used on the serial port can be used as UDP or TCP commands over Ethernet.

For more information and a detailed list of UDP and TCP control commands refer to the Annunicom Technical Documentation available on www.barix.com

9.4 Expert settings

There is also the possibility to disable some IP protocols. Change the IP address in the serial- , Telnet- or Web configuration to:

0.0.1.0 to disable AutoIP

0.0.2.0 to disable BOOTP

0.0.4.0 to disable DHCP

0.0.8.0 to disable IPZator

The values can be combined for example, 0.0.12.0 turns of DHCP and IPZator.

10 FAQ and Troubleshooting

Q: I don't see any status lights on at all.

A: Make sure the power cable is correctly plugged into the unit and make sure the power supply is plugged into the wall.

Q: Red status light is flashing red.

A: Make sure the network cable is plugged into the unit. The status light on the jack indicates if you are connected to the network or not. Make sure the Music Server program is running on the network. You can also ping the device to see if it's on your network.

Q: How do I ping the Annunicom to see if it's on my network?

A: You can ping any device on your network by opening a DOS command box.

Type ping and the IP address of the unit to see if you can get a response.

Example: ping 192.168.2.10

The proper response would be to see the message "reply from 192.168.2.10".

If you see the message "request timed out", it means that the Annunicom is not on your network or that you have entered the wrong numbers for the IP address.

Q: When I type in the IP address into the browser I get a "This Page Cannot Be Displayed" Message

A: This means that you cannot connect to the Annunicom. There could be a couple of different reasons. Make sure you are typing in the IP address correctly. Check the cables to make sure the Annunicom is properly connected to the network.

Q: Will the Annunicom work on my operating system?

A: The Annunicom works on virtually any operating system, to control the Annunicom a standard web browser is all you need.

Q: How can I prevent delays during speech transaction ?

A: There is no clear recommendation! This is depending from the customer's environment. But the delay is adjustable by the parameters play buffer, encoding quality and sampling frequency. A poor sound/voice quality will fill the default buffer slower than a good sound/voice quality. But note, a higher sound quality causes also much more network traffic !

11 Dictionary

DHCP

Short for Dynamic Host Configuration Protocol, DHCP is a protocol used to assign an IP address to a device connected to a Network.

DOS

Microsoft DOS (Disk Operating System) is a command line user interface. MS-DOS 1.0 was released in 1981 for IBM computers. While MS-DOS is not used commonly today, it still can be accessed from Windows 95, XP, Windows 98 or Windows NT by clicking Start / Run and typing command or CMD in Windows 2000.

IP

Short for Internet Protocol, the IP is an address of a computer or other network device on a network using IP or TCP/IP. Every device on an IP-based network requires an IP address to identify its location or address on the network.

Example: 192.168.2.10

IPzator

Barix IPzator™ technology is designed for the purpose that the Annunicom can create its own IP address according to the network structure in case it can't receive one from your network. If DHCP, AUTO IP or BOOTP fail, IPzator will create an IP address within the subnet and test it. If the address works and is not being used by another device on the network, it will give the address to the Annunicom.

MAC address

Abbreviation for Medium Access Control, a MAC is a unique address number formatted in hexadecimal format and given to each computer and/or network device on a computer network. Because a MAC address is a unique address a computer network will not have the same MAC address assigned to more than one computer or network device.

Example: A1:B2:C3:D4:E5:F6

Netmask

A number used to identify a sub network so that an IP address can be shared on a LAN (Local Area Network).

A mask is used to determine what subnet an IP address belongs to. An IP address has two components, the network address and the host address. For example, consider the IP address 150.215.17.009. Assuming this is part of a Class B network, the first two numbers (150.2) represent the Class B network address, and the second two numbers (.017.009) identify a particular host on this network. The Netmask would then be 255.255.0.0

Ping

Ping is a basic Internet program that lets you verify that a particular IP address exists and can accept requests. *Example: ping 192.168.2.10*

SonicIP

Barix SonicIP® technology is designed to vocally announce the Annunicom's current IP address. This makes it easier and faster to obtain the necessary network information. To make use of SonicIP plug in the included earphone into RCA audio out, connect the network and plug in the power supply. It will announce the address over the earphones right after power up.

Static IP

A Static IP is a fixed IP address that you assign manually to a device on the network. It remains valid until you disable it.

Telnet

Telnet is a user command and an underlying [TCP/IP protocol](#) for accessing remote computers. On the Web, [HTTP](#) and [FTP](#) protocols allow you to request specific files from remote computers, but not to actually be logged on as a user of that computer. With Telnet, you log on as a regular user with whatever privileges you may have been granted to the specific [application](#) and [data](#) on that computer.

Example: telnet 192.168.2.10

12 Legal Information

© 2014 Barix AG, Zurich, Switzerland.

All rights reserved.

All information is subject to change without notice.

All mentioned trademarks belong to their respective owners and are used for reference only.

Barix, Annunicom, SonicIP and IPzator are trademarks of Barix AG, Switzerland and are registered in certain countries.

For information about our devices and the latest version of this manual please visit www.barix.com.

Barix AG
Seefeldstrasse 303
8008 Zurich

SWITZERLAND

Phone: +41 43 433 22 11
Fax: +41 44 274 28 49

Internet

web: www.barix.com
email: sales@barix.com
support: support@barix.com
wiki: wiki.barix.com